

STANDARD OPERATION SHEET (PROCEDURE TYPE)

ED/ FRM/ 07 Rev 00

OPERATION NAME SAFETY FIRST (EQUIPMENT & INSTRUCTION) VITAL PORTION										
Nissan Serena C27 Auto Window Installation SOP							17/7/2020			
			 Make sure disconnect Negative(-) Terminal Make sure hand hold connector when unplu 				NG WY			
			- Make sure hard hold connector when thiplingging - Ensure 'click' sound when plug in connector			MGR OK Na	Nathan Low			
NO. I MAIN STEP TIME			KEY POINT	KEY POINT I REASON		DRAWINGS/PHOTO/PROCEES FLOW				
	Remove the sides plastic panel as shown.		Remove carefully.	The plastic clip on th						
	Remove the screw X1.					1	2			
3	Remove the Window Switch Assembly from the door panel.									
4	Disconnect all the connector from the window switch.					3	4			
5	Remove the nut X1 (spanner size 10)									
6	Remove the Door Panel from the car door (Driver).					5	6	1		
7	Remove the original window switch from the switch panel Note: 4 Locking points.					7	8			
8	Install the supply window switch to the switch panel.					1900				
REVIS	SION NO: E DATE:	TOOLS Spanner I Removal Torx Size	No 10 Tool	ED PARTS USED				SHEET NO.		



TC AUTO TOOLING SDN. BHD

STANDARD OPERATION SHEET (PROCEDURE TYPE)

ED/ FRM/ 07 Rev 00

OPER	ATION NAME	SAFETY FIRST (EQUIF	SAFETY FIRST (EQUIPMENT & INSTRUCTION) VITAL PORTION						
Nis	san Serena C27 Auto Window Installation SO	P - Make sure hand hold	Make sure disconnect Negative(-) Terminal and then wait at least 3 minutes Make sure hand hold connector when unplugging Ensure 'click' sound when plug in connector			DATE PREPARED BY MGR OK GK OK	17/7/2020 NG WY Nathan Low		
NO.	MAIN STEP TI	ME KE	Y POINT	RE	ASON		DRAWINGS/PHOTO/PROCI	ES FLOW	
	Using blade cutter to cut the black sealant as shown.	Just partially open	the black sealant.	As long as hand can connector.	access the door lock	9	10		
10	Route the supply wire as shown.								
	Disconnect the OE door lock connector and connect to supply T-joint connector as shown.	Stick back the seal connector connecte							
	Step 12 only for the Auto	o Window come with A	uto Folding Mirror Fur	ection (ontional)			Connector HERE	1	OE folding
	Connect the OE sides mirror connector to supply T-joint connector as shown.		ato rolung militor rui	iction (epitema)		11	12	P	mirror connector
	Connect all the connector to the window switch and cover back all the panel and screws.								
						13			
	Reinstall al After reassembly has be	al. ctions correctly.							
REVIS		OLS USED le cutter	MATERIALS USED	PARTS USED				2	SHEET NO.